

1977 Sofa Arm | 1977 Outdoor Sofa Arm 1978 High Back Sofa Arm

K I N G

Assembly | User Guide



Two people required for safe assembly


Opening Boxes: DO NOT use a knife to open the packaging as you may damage your furniture. Peel-off the tape, then lift and separate the cardboard flaps to open.

Please follow these Assembly | User Guide Instructions

Product Care

Arm Bracket


Compatible* for left-hand or right-hand configurations:




*Arm Bracket compatible with Standard Fixed Height Legs only: 45mm (1.75")
Not compatible with Height Adjustable Legs

Short Bracket


1




2




3




4




5




1




2




3



4




5




Long Bracket

1



2



3

